

5401	5402	5403	5404A	5404B	5404C	5405	5406	5407	5408	5409	5410	5411	5412	5413
5414	5415	5416	5417	5418	5419A	5419B	5419C	5420	5421A	5421B	5421C	5422	5423	

FUNCTION BLOCKS - FUNCTION DESIGNATIONS

6201	6201A	6201B	6201C	6201D	6201E	6201F	6201G	6201H	6201I
—	— AS —	— IA —	— PA —	— ES —	— GS —	— HS —	— NS —	— SS —	— WS —
6202	6203	6204A	6204B	6205	6206	6207	6208	6209	6210
6211	6212A	6212B	INSTRUMENT LINE SYMBOLS						

6301	6301A	6302	6303	6303A	6304	6304A	6305	6306	6306A	6307	6307A	6308	6309	6309A
6310	6310A	6311	6312	6312A	6314	6315	6316	6317	6317A	6318	6319	6320	6321	

GENERAL INSTRUMENT OR FUNCTION SYMBOLS

6401	6402	6403	6404	6405	6406	6407
6409				CONTROL VALVE BODY SYMBOLS, DAMPER SYMBOLS		

6501	6502	6505	6506	6507	6508	6509	6510	6511	6515
6503	6504	6512	6513	6514	6517	6516	ACTUATOR SYMBOLS		
IA	IA								
		6518	6519						